


# Solar Electric Night Light

For the Solatube Brighten Up® Series



Parts list		Quantity
1	Night light housing assembly	(1)
2	Mounting bracket assembly	(1)
3	Rechargeable battery NIMH AA 1500 mAh 1.2V	(2)

**PLEASE INSTALL THIS ACCESSORY AT STEP 13 OF THE MAIN SOLATUBE BRIGHTEN UP SERIES INSTALLATION GUIDE (ref ML-INST-BU14)**

Please note, the night-time performance of the Solar Powered Night Light is directly proportional to the charge received from the previous daylight hours. No maximum or minimum performance is therefore provided or guaranteed.

**1 Install mounting bracket**  
Remove paper liner from the back of the mounting bracket, position in place and then press firmly to secure to the bottom tube

(a) Remove paper liner

(b) Align bracket with tube seam

BOTTOM TUBE ASSEMBLY

**2 Install top tube (or extension tube) to bottom tube**  
Seat the top tube/extension tube over the mounting bracket

(a) TOP TUBE / EXTENSION TUBE

(b) Seat onto mounting bracket here.

**3 Install the housing assembly**  
Reach up inside the Solatube and slide the housing assembly into place in the mounting bracket.

(a)

(b)

**4 The Solar Electric Night Light installation is now complete**  
**PLEASE NOW CONTINUE WITH STEP 15 OF THE MAIN SOLATUBE INSTALLATION GUIDE**

To replace the batteries in the Solar Electric Night Light:

1. Remove the Solatube ceiling diffuser and lens.
2. Remove the Solar Electric Night Light housing assembly from the tube by gently sliding it up & off the mounting bracket.
3. Remove the old batteries from their compartment in the housing assembly.
4. Insert new batteries to the (+) and (-) marks inside the battery compartment then insert the housing assembly back into place over the mounting bracket.

Warning: Replace with only NiMH (nickel-metal-hydride) rechargeable batteries (NiMH AA 1500mAh 1.2v).

Always remove old, weak or worn-out batteries promptly and recycle or dispose of them in accordance with local and/or national regulations.